

Key:			
1	Transmission mounting face	22	Measuring point for lubricating
2	Measuring point for clutch oil pressure		oil pressure
5	Measuring point for oil pressure upstream	23	Transmission breather
	of filter	2.5	Oil dipstick
7	Filter chamber, sediment drain	26	Output
8	Input	32	Oil chamber drain
9	Bell housing for flange-mounting the en-	33	Oil filter
	gine (special scope of supply)	34	Emergency control
10	Engine-driven oil pump		(counter-enginewise rotation)
11, 12, 41	Measuring points for oil temperature	44	Emergency control (enginewise rotation,
13	Water connection flunges	46	Oil filling
15	Oil cooler	47	Inspection hole cover.
20	Oil drain		transmission housing
		105	Control lever for mechanical actuation